Two-Stage, General-Purpose Pressure Regulator Internally Threadless • Brass



Value Proposition:

With an inlet pressure up to 4,000 psig, Parker's IR6200 two-stage regulator offers high pressure capability with stable pressure control. This general-purpose series features a large, convoluted Hastelloy C-22® diaphragm that provides high corrosion resistance. Close tolerances and tight alignment of moving components minimizes hysteresis and improves cycle life.



Contact Information:

Parker Hannifin Corporation **Veriflo Division** 250 Canal Blvd. Richmond, California 94804

phone 510 235 9590 fax 510 232 7396 veriflo.sales@parker.com


www.parker.com/veriflo Mobile App: m.parker.com/veriflo


Product Features:


- Unique compression member loads the seal to the body without requiring a threaded nozzle or additional seals
- Internally threadless design reduces particle generation; low internal volume reduces purge times
- Cleaned for O₂ service is standard
- Positive upward and downward stops increase cycle life by preventing over stroking of the diaphragm




Flow Curves










RANGE TABLE				
Basic	Max Inlet PSIG			
Model	0.06 C _V	0.02 C _V	0.15 C _V	
IR6200	4,000	4,000	1,250	
IR6201	4,000	4,000	1,250	
IR6202	4,000	4,000	1,250	
IR6203	4,000	4,000	1,250	
IR6204	4,000	4,000	1,250	
IR6215	4,000	4,000	1,250	

Dimensional Drawing



OVERALL HEIGHT TABLE		
Basic Model	н	
IR6200	7.22 [183.4mm]	
IR6201	7.22 [183.4mm]	
IR6202	7.22 [183.4mm]	
IR6203	7.22 [183.4mm]	
IR6204	7.81 [198.4mm]	
IR6215	7.22 [183.4mm]	

Ordering Information

Build an IR6200 Series regulator by replacing the numbered symbols with an option from the corresponding tables below.

Contact factory for most up to date lead time information.

Blue = Configurations that have selections in blue may have an extended lead time and a minimum order quantity.



Finished Order: IR6202BK4P01304BN580

Basic Series

Range	Outlet Gauge
00 = 0 - 10 psig	0 - 30 psig
01 = 1 - 30 psig	0 - 60 psig
02 = 2 - 60 psig	0 - 100 psig
03 = 3 - 100 psig	0 - 200 psig
15 = 5 - 150 psig	0 - 200 psig
04 = 10 - 250 psi	g 0 - 400 psig

Sample: IR62

Body Material

B = Brass

Flow Capacity

= 0.06 Cv Standard 0.02 Cv

= 0.15 Cv

Seat Material

= PCTFE

Porting

= 2 Ports No X required for gauges, inlet & outlet ports only

= 3 Ports One X for gauge port

4P = 4 Ports Two X's for gauge ports

4PB = 4 Ports One X for gauge port

5P = 5 Ports Two X's for gauge ports

6P = 6 Ports Two X's for gauge ports See Regulator Porting Guide for additional options and port layouts.

Note: Ports may be plugged for NPT threaded product.

Outlet Gauge

Outlet Gauge	Basic Series
03 = 0 - 30 psig	IR6200
OL = 0 - 60 psig	IR6201
01 = 0 - 100 psig	IR6202
2 = 0 - 200 psig	IR6203
4 = 0 - 400 psig	IR6204

X = No Gauge

Additional ranges available upon request

Inlet Gauge

= No Gauge

30 = 3,000 psig Standard

20 = 2,000 psig with the 0.15 Cv option

40 = 4,000 psig

Additional ranges available upon request

Port Style

= 1/8" NPT Female

= 1/4" NPT Female

= 3/8" NPT Female

4T = 1/4" A-LOK®

6T = 3/8" A-LOK®

All Gauge ports are 1/4" NPT Female

Port Mounting

B = Standard - No other options

Optional Features

This section can have multiple options

= True Ported Body No plugs Tamper Proof Not available with M option

Metal Knob Not available with G

option

Nickel Plate

В

R2 = Relief Valve 4PB, 5P and 6P Only

= Self Relieving

= Outlet Valve NV17SB44MF

Note: Panel Mount Option:

Order Panel Nut Ring p/n: 41900363 as a separate line item.

Vent Muffler Option:

Order Vent Muffler p/n: 46600581

as a separate line item.

CGA#

320, 330, 350, 510, 580 or 590 Do not exceed the rated pressure of the CGA connection.

Specifications

Materials of Construction		
Wetted		
Body Options	Brass (std) or Nickel Plated Brass	
Compression Member	Inconel 625®	
Diaphragm	Hastelloy C-22®	
Poppet	Phosphor Bronze	
Poppet Spring	Inconel X750®	
Seat	PCTFE	
Carrier	316L Stainless Steel	
Washer Backup	Phosphor Bronze	
O-ring Backup	FKM	
Inlet Screen / Filter	Copper and Phosphor Bronze	
Self Relieving Seat	PEEK™	
Non-wetted		
Cap	Nickel Plated Brass	
Nut	Nickel Plated Brass	
Knob Options	ABS (std) (ambient temp) or Aluminum	

For additional information on materials of construction, functional performance and operating conditions, see Regulator Technical Bulletin.

Functional Performance		
Design		
Burst Pressure	12,000 psig (828 barg)	
Proof Pressure	6,000 psig (414 barg)	
Flow Capacity		
C _V Options	$C_V 0.06$ (std), $C_V 0.02$, $C_V 0.15$	
Leak Rate		
Internal	Bubble Tight	
External	Bubble Tight	
Supply Pressure Effect	Based upon C _V Option	
0.02 C _V	0.01 psig/100 psig (0.0007 barg/7 barg)	
0.06 C _V	0.01 psig/100 psig (0.0007 barg/7 barg)	
0.15 C _V	0.02 psig/100 psig (0.0014 barg/7 barg)	
Internal Volume	8.1 cc without fittings	
Approx. Weight	3.5 lbs. (1.6 kg)	
Operating Conditions		
Maximum Inlet	Refer to Range Table for specific information	
Outlet Options	0-10 psig (.7 barg), 1-30 psig (2 barg), 2-60 psig (4 barg), 3-100 psig (7 barg), 5-150 psig (10 barg),10-250 psig (17 barg)	
Temperature	-40°F to 150°F (-40°C to 66°C)	

A-LOK® is a registered trademark of Parker Hannifin Corporation. Hastelloy C-22® and Hastelloy C-276® are registered trademarks of Haynes International, Inc. Inconel® is a registered trademark of Special Metals Corporation. PEEK™ is a trademark of Victrex plc.

OFFER OF SALE:

The items described in this document are hereby offered for sale by Parker Hannifin Corporation, its subsidiaries or its authorized distributors. This offer and its acceptance are governed by the provisions stated in the detailed "Offer of Sale" elsewhere in this document or available at www.parker.com/veriflo



WARNING USER RESPONSIBILITY

FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE. THIS DOCUMENT IS FOR REFERENCE ONLY. PLEASE CONSULT FACTORY FOR LATEST PRODUCT DRAWINGS AND SPECIFICATIONS.

This document and other information from Parker Hannifin Corporation, its subsidiaries and authorized distributors provide product or system options for further investigation by users having technical expertise.

The user, through its own analysis and testing, is solely responsible for making the final selection of the system and components and assuring that all performance, endurance, maintenance, safety and warning requirements of the application are met. The user must analyze all aspects of the application, follow applicable industry standards, and follow the information concerning the product in the current product catalog and in any other materials provided from Parker or its subsidiaries or authorized distributors.

To the extent that Parker or its subsidiaries or authorized distributors provide component or system options based upon data or specifications provided by the user, the user is responsible for determining that such data and specifications are suitable and sufficient for all applications and reasonably foreseeable uses of the components or systems.

The products described herein, including without limitation, product features, specifications, designs, availability and pricing are subject to change by Parker Hannifin Corporation and its subsidiaries at any time without notice.

Proposition 65 Warning: This product contains chemicals known to the state of California to cause cancer or birth defects or other reproductive harm.

©2007 Parker Hannifin Corporation



Use mobile device to scan this QR Code.

LitPN: 25000227 Rev: L Date of Issue 09/2016

