

PROTÉGÉ MULTI GAS MONITOR

ACCESSORIES

The Protégé is compatible with several "must have" accessories. These accessories provide multi-monitor charging, remote sampling, automated bump test and calibration.



Parasitic Sample Draw Pump

- The Pump Kit comes with a parasitic sample draw pump, 30cm probe with dust and water filter and 3m Tygon sample tube.
- When fitted, the sample draw pump maintains a small, ergonomic design allowing for remote sampling.
- Runs off the power source of the gas monitor with a run time of up to 12 hours.
- Sample draw distance of up to 30 metres.

Masterdock Station

- The Masterdock is a fully automated calibration and bump test station.
- High speed calibration with low operating costs improves efficiency.
- Automation saves time and reduces the risk of human error.
- Stores data in a text file making it easy to keep track of testing.
- Uses 103L, 58L or 34L cylinders and is battery or AC powered.



Multi-Charger, Single Charger and Vehicle Charger

- The Multi-charger enables users to charge up to six Protégé gas monitors simultaneously.
- Single charger is supplied with USB communication cable for configuring gas monitor settings and data download.
- 12V DC adaptor allows for charging from the car lighter.

Order Information

Part Number	Description
093-0526	Masterdock - automated bump test & calibration station, AC or battery powered. (Utilises 103L 6D or 58L 8AL or 34L 2AL cylinder)
096-3271	Pump Kit (Pump, Probe, Tubing)
096-3283-4	Six Unit Multi-Charger
0770018	0.5LPM Regulator for 103L 6D, 58L 8AL or 34L 2AL cylinders
003330	58L Calibration/Bump Test Gas CO/H ₂ S/LEL/O ₂ (Methane)
028-0052	Vehicle Charger