# Pressure sensor For general industrial applications Model A-10

WIKA data sheet PE 81.60







for further approvals see page 9

# **Applications**

- Machine building
- Shipbuilding
- Measurement and control technology
- Hydraulics and pneumatics
- Pumps and compressors

## **Special features**

- Measuring ranges from 0 ... 0.05 to 0 ... 1,000 bar
- Non-linearity 0.25 % or 0.5 %
- Output 4 ... 20 mA, DC 0 ... 10 V, DC 0 ... 5 V and others
- Electrical connection: Angular connector form A and C, circular connector M12 x 1, cable outlet 2 m
- Process connection G ¼ A DIN 3852-E, ¼ NPT and others



Pressure sensor, model A-10

# **Description**

The model A-10 pressure sensor for general industrial applications is not only notable for its compact design, but it also offers excellent quality at an extremely competitive price.

The user can choose between a non-linearity of 0.25% and 0.5%. A free test protocol provides information on the measuring points recorded during manufacture.

The model A-10 is set up for worldwide use through the international cULus and EAC certification. The various pressure units and process connections required for particular operating conditions are available at short notice.



# **Measuring ranges**

Gaug	Gauge pressure							
bar	Measuring range	0 0.05	0 0.1	0 0.16	0 0.25	0 0.4	0 0.6	0 1
	Overload safety	0.2	0.2	1	1	1	3	3
	Measuring range	0 1.6	0 2.5	0 4	0 6	0 10 <sup>1)</sup>	0 16 <sup>1)</sup>	0 25 <sup>1)</sup>
	Overload safety	3.2	5	8	12	20	32	50
	Measuring range	0 40	0 60	0 100	0 160	0 250	0 400	0 600
	Overload safety	80	120	200	320	500	800	1,200
	Measuring range	0 1,000						
	Overload safety	1,500						
inWC	Measuring range	0 20	0 40	0 60	0 80	0 100	0 120	0 150
	Overload safety	84	84	400	400	400	400	400
	Measuring range	0 200	0 250	0 400				
	Overload safety	400	1,200	1,200				
psi	Measuring range	0 1	0 5	0 15	0 25	0 30	0 50	0 100
	Overload safety	3	14.5	45	60	60	100	200
	Measuring range	0 160 <sup>1)</sup>	0 200 <sup>1)</sup>	0 300 <sup>1)</sup>	0 500	0 1,000	0 1,500	0 2,000
	Overload safety	290	400	600	1,000	1,740	2,900	4,000
	Measuring range	0 3,000	0 5,000	0 10,000				
	Overload safety	6,000	10,000	17,400				

<sup>1)</sup> If the medium water is measured, a higher overload safety is recommended.

Absolute pressure								
bar	Measuring range	0 0.1	0 0.16	0 0.25	0 0.4	0 0.6	0 1	0 1.6
	Overload safety	1	1	1	1	3	3	3.2
	Measuring range	0 2.5	0 4	0 6	0 10	0 16	0 25	
	Overload safety	5	8	12	20	32	50	
inWC	Measuring range	0 40	0 60	0 80	0 100	0 120	0 150	0 200
	Overload safety	400	400	400	400	400	400	400
	Measuring range	0 250	0 400					
	Overload safety	1,200	1,200					
psi	Measuring range	0 5	0 15	0 25	0 30	0 50	0 100	0 150
	Overload safety	14.5	45	60	60	100	200	290
	Measuring range	0 200	0 300					
	Overload safety	400	600					

Vacuu	ım and +/- measurin	g range				
bar	Measuring range	-0.025 +0.025	-0.05 0	-0.05 +0.05	-0.05 +0.15	-0.05 +0.2
	Overload safety	±0.2	±0.2	±0.2	1	1
	Measuring range	-0.05 +0.25	-0.1 0	-0.1 +0.1	-0.15 +0.15	-0.16 0
	Overload safety	1	±0.2	1	1	1
	Measuring range	-0.2 +0.2	-0.25 0	-0.25 +0.25	-0.3 +0.3	-0.4 0
	Overload safety	1	1	1	3	1
	Measuring range	-0.5 +0.5	-0.6 0	-1 0	-1 +0.6	-1 +1.5
	Overload safety	3	3	3	3.2	5
	Measuring range	-1 +3	-1 +5	-1 +9 <sup>1)</sup>	-1 +15 <sup>1)</sup>	-1 +24 <sup>1)</sup>
	Overload safety	8	12	20	32	50
nWC	Measuring range	-10 +10	-20 0	-20 +20	-40 0	-40 +40
	Overload safety	±80	±80	±80	±80	±80
	Measuring range	-50 +50	-60 0	-75 +75	-80 0	-100 0
	Overload safety	400	400	400	400	400
	Measuring range	-100 +100	-120 0	-125 +125	-150 0	-200 +200
	Overload safety	400	400	1,200	400	1,200
	Measuring range	-250 0				
	Overload safety	1,200				
osi	Measuring range	-1 0	-30 inHg 0	-30 inHg +15	-30 inHg +30	-30 inHg +60
	Overload safety	±3	45	60	60	150
	Measuring range	-30 inHg +100	-30 inHg +160 <sup>1)</sup>	-30 inHg +200 <sup>1)</sup>	-30 inHg +300 <sup>1)</sup>	
	Overload safety	250	350	450	600	

<sup>1)</sup> If the medium water is measured, a higher overload safety is recommended.

The given measuring ranges are also available in mbar, kg/cm², MPa and kPa.

Other measuring ranges available on request.

3-fold overload safety available on request.

# Vacuum tightness

Yes (for restrictions see overload safety)

## **Output signals**

Output signals					
Current (2-wire)	4 20 mA				
Voltage (3-wire)	DC 0 10 V				
	DC 0 5 V				
	DC 1 5 V				
	DC 0.5 4.5 V				
Ratiometric (3-wire)	DC 0.5 4.5 V				

Other output signals on request

#### Load in $\Omega$

Current (2-wire):  $\leq$  (power supply - 8 V) / 0.02 A Voltage (3-wire): > maximum output signal / 1 mA

Ratiometric (3-wire): > 10k

# **Voltage supply**

Output signal	Power supply		
	Standard	Option	
4 20 mA	DC 8 30 V	DC 8 35 V 1) 2)	
DC 0 10 V	DC 14 30 V	DC 14 35 V	
DC 0 5 V <sup>3)</sup>	DC 8 30 V	DC 8 35 V	
DC 1 5 V	DC 8 30 V	DC 8 35 V	
DC 0.5 4.5 V	DC 8 30 V	DC 8 35 V	
DC 0.5 4.5 V ratiometric	DC 5 V ± 10 %	-	

- 1) Not possible with non-linearity 0.25 % BFSL 2) Only possible for temperatures up to 80 °C (176 °F) 3) Not possible with measuring ranges  $\leq$  0.1 bar (or equivalent)

The power supply for the pressure sensor must be made via an energy-limited electrical circuit in accordance with section 9.3 of UL/EN/IEC 61010-1, or an LPS per UL/EN/IEC 60950-1, or class 2 in accordance with UL1310/UL1585 (NEC or CEC). The power supply must be suitable for operation above 2,000 m should the pressure sensor be used at this altitude.

## **Total current consumption**

Current (2-wire): Signal current, max. 25 mA

Voltage (3-wire): 8 mA Ratiometric (3-wire): 8 mA

# **Accuracy specifications**

Optionally the model A-10 is available with an improved non-linearity. Depending on the selected non-linearity the following values result:

	Standard	Option
Non-linearity per BFSL (IEC 61298-2)		
■ Measuring range ≤ 0.1 bar	≤ ±0.5 % of span	F
■ Measuring range > 0.1 bar	≤ ±0.5 % of span	$\leq$ ±0.25 % of span <sup>1)</sup>
Measuring deviation of the zero signal <sup>2) 3)</sup>		
■ 4 20 mA	≤ ±0.3 % of span	≤ ±0.2 % of span
■ DC 0 10 V	≤ ±0.5 % of span	≤ ±0.4 % of span
■ DC 0 5 V <sup>4)</sup>	≤ ±0.6 % of span	F
■ DC 1 5 V	≤ ±0.3 % of span	≤ ±0.2 % of span
■ DC 0.5 4.5 V	≤ ±0.3 % of span	≤ ±0.2 % of span
■ DC 0.5 4.5 V ratiometric	≤ ±0.3 % of span	≤ ±0.2 % of span
Accuracy at room temperature 5)		
■ Measuring range ≥ 0.6 bar	≤±1 % of span	≤ ±0.5 % of span
■ Measuring range ≥ 0.4 bar	≤ ±1.2 % of span	≤ ±0.7 % of span
■ Measuring range ≥ 0.25 bar	≤ ±1.3 % of span	≤ ±0.8 % of span
■ Measuring range ≥ 0.16 bar	≤ ±1.5 % of span	≤±1 % of span
■ Measuring range ≥ 0.1 bar	≤ ±1.8 % of span	-
■ Measuring range ≥ 0.05 bar	≤ ±2.4 % of span	F

In case of occasional faults due to electrostatic discharges, a temporary measuring error of up to ±2.5 % can occur.

# Non-repeatability (per IEC 61298-2)

Measuring range ≤ 0.1 bar: ≤ 0.2 % of span Measuring range > 0.1 bar: ≤ 0.1 % of span

#### Signal noise

 $\leq$  ±0.3 % of span

(≤ ±0.2 % of span on request)

# Temperature error at 0 ... 80 °C (32 ... 176 °F)

Typical: ≤ ±1 % of span Maximum: ≤ ±2.5 % of span

Maximum ≤ ±1.5 % of span on request

#### Long-term drift (per IEC 61298-2)

Measuring ranges ≤ 0.1 bar:  $\leq \pm 0.5$  % of span <sup>1)</sup> Measuring ranges  $\leq$  0.4 bar:  $\leq$  ±0.2 % of span Measuring ranges > 0.4 bar:  $\le \pm 0.1$  % of span

# Temperature hysteresis -30 ... +100°C (-22 ... +212 °F) for measuring ranges < 0.6 bar

Measuring range	Gauge pressure	Absolute pressure
≥ 0.40 bar	≤ ±0.2 % of span	≤ ±0.2 % of span
≥ 0.25 bar	≤ ±0.3 % of span	≤ ±0.3 % of span
≥ 0.16 bar	≤ ±0.5 % of span	≤ ±0.5 % of span
≥ 0.10 bar	≤ ±0.7 % of span	≤ ±0.8 % of span
≥ 0.05 bar	≤ ±1.4 % of span	-

<sup>1)</sup> Not possible with output signal DC 0 ... 5 V

<sup>2)</sup> Measuring ranges  $\leq$  0.1 bar (or equivalent) only possible with  $\leq$  ±0.5 % of span.

<sup>3)</sup> Outside reference conditions the temperature hysteresis has to be added for measuring ranges < 0.6 bar. 4) Not possible with measuring range ≤ 0.1 bar (or equivalent)

<sup>5)</sup> Including non-linearity, hysteresis, zero offset and end value deviation (corresponds to measured error per IEC 61298-2), calibrated in vertical mounting position with process connection facing downwards

<sup>1)</sup> Outside reference conditions the temperature hysteresis has to be added for measuring ranges < 0.1 bar.

## Time response

Measuring range	Settling time	Switch-on time
≥ 0.4 bar	< 4 ms <sup>1)</sup>	< 15 ms
≥ 0.05 bar	< 1 min	< 1 min

<sup>1) 1</sup> ms on request

# **Operating conditions**

## Ingress protection (per IEC 60529)

see table "Specifications"

#### Vibration resistance

10 g (IEC 60068-2-6, under resonance) 1) 20 g available on request 2)3)

1) With GL approval and measuring range 0 ... 0.6 bar only feasible with an accuracy of 1 % 2) With GL approval only feasible for measuring range > 0 ... 1 bar 3) From -30 °C (-22 °F)

#### **Shock resistance**

500 g (IEC 60068-2-27, mechanical) 100 g at -40 °C (-40 °F)

#### Service life

Measuring range > 0.1 bar: 100 million load cycles Measuring range ≤ 0.1 bar: 10 million load cycles

#### Permissible temperature ranges

Standard		Option			
		Voltage signal	Current signal <sup>1) 2)</sup>		
Ambient	0 +80 °C	-30 +100 °C	-40 +100 °C <sup>3)</sup>		
	(32 176 °F)	(-22 +212 °F)	(-40 +212 °F)		
Medium	0 +80 °C	-30 +100 °C	-40 +100 °C <sup>3)</sup>		
	(32 176 °F)	(-22 +212 °F)	(-40 +212 °F)		
Storage	-40 +70 °C	-40 +70 °C	-40 +70 °C		
	(-40 +158 °F)	(-40 +158 °F)	(-40 +158 °F)		

Restrictions and derating of the ambient temperature depend on the medium temperature. Depending on the choice of sealing on the process connection, there may be limitations in the permissible temperature range (for limitations see "Process connections, sealings").

# Reference conditions (per IEC 61298-1)

## Temperature

15 ... 25 °C (59 ... 77 °F)

#### Atmospheric pressure

860 ... 1,060 mbar (12.5 ... 15.4 psi)

#### Humidity

45 ... 75 % relative

#### **Power supply**

DC 24 V

## **Mounting position**

as required

<sup>1)</sup> With cULus approval the minimum ambient and medium temperature is -30  $^{\circ}$ C (-22  $^{\circ}$ F) 2) Only with power supply DC 8 ... 30 V 3) Only with housed installation site that is protected from condensation

## **Process connections**

Standard	Thread size				
EN 837	G 1/8 B 1)				
	G 1/4 B				
	G 1/4 female				
	G 1/4 female, with flange connection 2)				
	G % B				
	G 1/2 B				
DIN 3852-E 3) 4)	G 1/4 A				
	G ½ A				
	M14 x 1.5				
ANSI/ASME B1.20.1	1/8 NPT <sup>1)</sup>				
	1/4 NPT				
	1/4 NPT female				
	½ NPT				
DIN 16288	M20 x 1.5				
ISO 7	R 1/4				
	R 3/8				
	R ½				
KS	PT 1/4				
	PT ½				
	PT 3/8				
SAE J514 E 3) 4)	7/16-20 UNF O-ring BOSS				

- Maximum measuring range 400 bar
   Maximum measuring range 100 bar
   Maximum overload safety 600 bar
   Maximum permissible temperature -20 ... +100 °C (-4 ... +212 °F)

## **Pressure port**

	Pressure port	Possible process connections
Standard	3.5 mm	All
Option 1	0.6 mm	All male threads
Option 2	0.3 mm	All male threads
Option 3	6.0 mm	G ¼ A and ¼ NPT

Optionally a T-restrictor is possible for the following process connections:

- G 1/4 B
- G 3/8 B
- G ½ B
- M20 x 1.5

## **Sealings**

For the process connections of the following standards the listed sealing materials are available.

Standard	Standard	Option
EN 837	Copper	Stainless steel
DIN 3852-E	NBR	FKM
DIN 16288	Copper	Stainless steel
SAE J514 E	NBR	FKM

The sealings listed under "Standard" are included in the delivery.

## **Electrical connections**

Designation	Ingress protection 3)	Wire cross- section	Cable diameter	Cable material
Angular connector DIN 175301-803 A				
■ with mating connector	IP65	up to a max. 1.5 mm <sup>2</sup>	6 8 mm	-
■ with moulded cable	IP65	3 x 0.75 mm <sup>2</sup>	6 mm	PUR
Angular connector DIN 175301-803 C				
■ with mating connector	IP65	up to a max. 0.75 mm <sup>2</sup>	4.5 6 mm	-
■ with moulded cable	IP65	4 x 0.5 mm <sup>2</sup>	6.2 mm	PUR
Circular connector M12 x 1 (4-pin)				
■ without mating connector	IP67	-	-	-
straight with moulded cable	IP67	3 x 0.34 mm <sup>2</sup>	4.3 mm	PUR
angled with moulded cable	IP67	3 x 0.34 mm <sup>2</sup>	4.3 mm	PUR
Cable outlet				
■ unshielded ¹)	IP67	3 x 0.34 mm <sup>2</sup>	4 mm	PUR
■ OEM version, unshielded <sup>2)</sup>	IP67	3 x 0.14 mm <sup>2</sup>	2.85 mm	TPU

Mating connectors (with and without cable) are also separately available as accessories. Cable lengths of 2 m or 5 m are available.

#### **Short-circuit resistance**

S+ vs. 0V

## Reverse polarity protection

U<sub>B</sub> vs. 0V

no reverse polarity protection with ratiometric output signal

#### Insulation voltage

DC 500 V

## **Connection diagrams**

All connectors with moulded cable have the same colour assignment as the unshielded cable outlet.

Angular connector DIN 175301-803 A				
		2-wire	3-wire	
[3 © ]	$U_{B}$	1	1	
	0V	2	2	
2	S+		3	

Angular connector DIN 175301-803 C				
2-wire 3-wire				
7	U <sub>B</sub>	1	1	
(13 (6) 1)	0V	2	2	
2	S+		3	

Circular connector M12 x 1 (4-pin)				
		2-wire	3-wire	
	U <sub>B</sub>	1	1	
4 • • 3	OV	3	3	
	S+		4	

Cable outlet, unshielded			
2-wire 3-wire			
	U <sub>B</sub>	brown	brown
	0V	blue	blue
	S+	-	black

Cable outlet, OEM version, unshielded				
2-wire 3-wire				
	U <sub>B</sub>	brown	brown	
	0V	blue	blue	
	S+		black	

## Legend

Positive power supply terminal

0V Negative power supply terminal

Analogue output

<sup>1)</sup> Not feasible with GL approval
2) up to a max. 90 °C (194 °F)
3) The stated ingress protection (per IEC 60529) only applies when plugged in using mating connectors that have the appropriate ingress protection.

## **Materials**

#### **Wetted parts**

< 10 bar (150 psi): Stainless steel 316L

 $\geq$  10 bar (150 psi): Stainless steel 316L and PH steel  $\leq$  0 ... 25 bar (400 psi) abs.: Stainless steel 316L

#### Non-wetted parts

- Stainless steel 316L
- HNBR
- PA

For sealing materials see "Process connections" For cable materials see "Electrical connections"

#### Pressure transmission medium

< 0 ... 10 bar (150 psi) gauge: Synthetic oil  $\leq$  0 ... 25 bar (400 psi) absolute: Synthetic oil  $\geq$  0 ... 10 bar (150 psi) gauge: Dry measuring cell

## **Approvals**

Logo	Description	Country
CE	EU declaration of conformity  ■ EMC directive  Emission (group 1, class B) and interference immunity (industrial application)  ■ Pressure equipment directive	European Community
CUL US US	UL <sup>1)</sup> Safety (e.g. electr. safety, overpressure,)	USA and Canada
EAC	EAC ■ Electromagnetic compatibility	Eurasian Economic Community
©	GOST Metrology, measurement technology	Russia
6	KazInMetr Metrology, measurement technology	Kazakhstan
	MTSCHS Permission for commissioning	Kazakhstan
<b>(</b>	BelGIM Metrology, measurement technology	Belarus
•	UkrSEPRO Metrology, measurement technology	Ukraine
	Uzstandard Metrology, measurement technology	Uzbekistan
<b>GL</b>	DNV GL <sup>1)</sup> Ships, shipbuilding (e.g. offshore)	Germany
	CRN Safety (e.g. electr. safety, overpressure,)	Canada

<sup>1)</sup> not for measuring ranges < 0.6 bar and not for medium temperature -40 ...+100  $^{\circ}$ C (-40 ...+212  $^{\circ}$ F)


## Manufacturer's information and certifications


Logo	Description
<b>@</b>	China RoHS conformity SJ/T 11364-2014


Approvals and certificates, see website


## **Dimensions in mm**


#### Pressure sensor

















## **Process connections**




G	L1
G 1/4 A DIN 3852-E	14
G 1/2 A DIN 3852-E	17
M14 x 1.5	14





G	L1
G 1/4 B EN 837	13
G % B EN 837	16
G 1/2 B EN 837	20
M20 x 1.5	20




G	L1
7/16-20 UNF BOSS	12.85










G	L1	L2	D1
1/4 NPT	20	14	Ø 25



G	L1
G 1/8 B EN 837	10








G 1/4 female, with flange connection	For dimensions see drawing

For information on tapped holes and welding sockets, see Technical information IN 00.14 at www.wika.com

# **Accessories and spare parts**



## **Mating connector**

Designation	Order number			
	without cable	with 2 m cable	with 5 m cable	
Angular connector DIN 175301-803 C	1439081 <sup>1)</sup>	11225823	11250194	
Angular connector DIN 175301-803 A				
■ with cable gland, metric	11427567	11225793	11250186	
■ with cable gland, conduit	11022485	-	-	
Circular connector M12 x 1, 4-pin				
■ straight	2421262	11250780	11250259	
■ angled	2421270	11250798	11250232	

<sup>1)</sup> Connector not permissible for A-10 with GL approval

#### Sealings for mating connectors

Designation	Order number		
	Blue (WIKA)	Brown (neutral)	
Angular connector DIN 175301-803 A	1576240	11437902	
Angular connector DIN 175301-803 C	11169479	11437881	

#### Sealings for process connection

Designation	Order number			
	Cu	Stainless steel	NBR	FKM
G 1/4 EN 837	11250810	11250844	-	-
M14 x 1.5	-	-	1537857	1576534
G ½ EN 837	11250861	11251042	-	-
M20 x 1.5	11250861	11251042	-	-
G 1/8 EN 837	11251051	-	-	-
G 1/4 DIN 3852-E	-	-	1537857	1576534
G ½ DIN 3852-E	-	-	1039067	1039075

Only use the accessories and spare parts listed, otherwise it could lead to the loss of the approval.

#### **Ordering information**

Model / Measuring range / Output signal / Power supply / Non-linearity / Temperature range / Process connection / Sealing / Electrical connection

© 2011 WIKA Alexander Wiegand SE & Co. KG, all rights reserved.

The specifications given in this document represent the state of engineering at the time of publishing. We reserve the right to make modifications to the specifications and materials.

Page 12 of 12

WIKA data sheet PE 81.60 · 03/2017



WIKA Alexander Wiegand SE & Co. KG Alexander-Wiegand-Straße 30 63911 Klingenberg/Germany Tel. +49 9372 132-0 Fax +49 9372 132-406 info@wika.de www.wika.de